

PG2500 / PG2500EX INSTALLATION ALERT

GMC	ACADIA	V6 3.6L	2011 - 2018
CHEVROLET	TRAVERSE	V6 3.6L	2011 - 2018
BUICK	ENCLAVE	V6 3.6L	2011 - 2018

The location of the oil filter on this vehicle makes it particularly difficult to reach. The only access is from above, with a reach of almost 22 inches down from the valence. To further complicate the installation, visibility of the mounting plate and stud is extremely limited (see the photo below).



Installation Tips:

- Use stool to stand on - this will give you better access and visibility
- Wear "Heat Sleeve", otherwise you need to wait 15-30 minutes for the engine to cool-off
- Mostly likely the surrounding parts are contaminated with mud or debris. Use care in fitting the filter carefully to the mounting stud. If you feel that the filter touched any other parts, it would be best to take it out and make sure the gasket and the thread are clean
- Use caution upon screwing the filter. It is recommended to turn the filter counter clock to catch the first thread, then screw it in clockwise.
- Make sure to tighten the filter at least $\frac{3}{4}$ of a turn
- If you feel that $\frac{3}{4}$ -1 turns were not reached, we highly recommend using end-cap wrench to secure the filter
- Add oil to the proper level, start engine and carefully check for leaks